

# AmpUp Driver App Quick Start Guide

Welcome to AmpUp! This guide will get you charging in no time. If you ever need assistance, we're here to help! Give us a call at **1-833-692-6787** or send an email to **support@ampup.io**.



## 1 Download & Launch the App

Download the latest version of the AmpUp App from the **Apple App Store** or **Google Play** store.

**Important:** When you open the app for the first time, you should enable push notifications and grant access to your camera and location to take advantage of the app's full features.

## 2 Create Your Account

When you first launch the AmpUp app, the QR code reader is active by default. To create an account:

- + Select **SETTING** in the bottom menu.
- + Select **SIGN UP** (in green, to the right of "Forgot password?") or create an account with your Apple, Google, or Facebook ID.

## 3 Activate Your Account

Once you've created an account, you'll receive an activation email from AmpUp. Click the link within the email to activate your account.

## 4 Login To Your Account

Once your account is activated, return to the app and select **SETTING** in the bottom menu. Sign in with your email address and password or with your Apple, Google, or Facebook ID.

## 5 Add Payment & RFID

To use public charging, you need to add a payment method and optional RFID.

- + Select **SETTING** in the bottom menu, then select **PAYMENTS & RFID**.
- + To add a payment method, tap **ADD A PAYMENT METHOD**, then enter your credit card details or select Apple Pay or Google Pay and follow the prompts.
- + To order an RFID card, click **AMPUP RFID**. To link an existing RFID, click **LINK MY OWN** and follow the instructions on screen.

## 6 Start Charging!

Select **CHARGE** in the bottom menu to open the QR code scanner or use the **MAP** to find and reserve chargers.